



Lenovo ThinkPad T420s Keyboard Replacement

How to replace the keyboard on the Lenovo ThinkPad T420s.

Written By: Alex Cabrera



INTRODUCTION



If you are experiencing sticky, unresponsive keys, you may need a new keyboard. This guide shows you how to replace your laptop's keyboard.



TOOLS:

- [Metal Spudger](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Keyboard



- Flip your laptop over so the bottom is facing up.
- Remove the memory panel by removing two black 5mm screws using the Phillips #0.
- Remove the memory panel.

Step 2



- Remove the two 5mm screw using the Phillips #0 screwdriver.
- Flip the laptop back over and open it.

Step 3



- Gently push down on the keyboard and slide it towards the screen. This will pop the bottom of the keyboard out of the casing.

i The best place to push is on the frame of the keyboard by the power button.

- Using the metal spudger, lift and slide out the keyboard.

! When lifting the keyboard do not remove it completely because a cable will still be connected to the laptop.

Step 4



- Remove the orange cable by lifting up on the tab on the end of the ribbon connection.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-16 05:18:33 PM.